



If the power fails, upsd finds out about through the driver. It sets the UPS status to "ON BATTERY"

The clients (upsmon) continually query upsd, so they find out about the power failure immediately.

- upsmon on the server machine queries over the loopback device.
- upsmon on the client machines queries over the network.

upsmon on the server